



COMPANY CAPABILITIES
& CERTIFICATIONS

MARCH 2021



Transport
Canada

Transports
Canada

Certificate of Approval

This is to certify that

Clearwater Defense Systems Corp

of

Langley, BC

Approved Maintenance Organization

84-12

is approved pursuant to CAR 573.02 for the maintenance of aeronautical products, and holds ratings in the following categories:


Components

NDT

Structures

The scope of privileges applicable to each category is limited to that specified in the respective rating documents that accompany this certificate, and is conditional upon compliance with the approved procedures and limitations specified in the organization's maintenance policy manual.

Signed: _____


Darrell Thody
For the Minister of Transport

Dated: 2018-11-29

Supersedes certificate dated: 2018-11-15



This Certificate is not transferable. The approval is valid until surrendered, suspended or canceled.

Canada



Transport
Canada

Transports
Canada

Approved Maintenance Organization Ratings

– NDT Category –

Clearwater Defense Systems Corp

Approved Maintenance Organization 84-12

is authorized to inspect aeronautical products, using the Non Destructive Testing techniques listed below, within the scope of work shown and subject to any further limitations specified in the maintenance policy manual.

Rating	Scope of work	Effective Date
Liquid penetrant inspection	As specified in company manual	2018-11-16
Magnetic particle inspection	As specified in company manual	2018-11-16

Issued: 2018-11-16

Signed:



Darrell Thody
For the Minister of Transport

Supersedes certificate dated: 2018-11-15

Canada



Transport
Canada

Transports
Canada

Approved Maintenance Organization Ratings

– Component Category –

Clearwater Defense Systems Corp

Approved Maintenance Organization 84-12

is authorized to perform maintenance, other than specialized welding or non-destructive testing, on the kinds of components listed below, within the scope of work shown and subject to any further limitations specified in the maintenance policy manual.

Rating	Scope of work	Effective Date
Aircraft components	As specified in company manual	2018-11-16
Engine components & accessories	As specified in company manual	2018-11-15
Hydraulic components	As specified in company manual	2018-11-16
Powertrain components	As specified in company manual	2018-11-16

Issued: 2018-11-16

Signed:

Darrell Thody
For the Minister of Transport

Supersedes certificate dated: 2018-11-15

Canada



Transport
Canada

Transports
Canada

Approved Maintenance Organization Ratings

– Structure Category –

Clearwater Defense Systems Corp


Approved Maintenance Organization 84-12

is authorized to perform maintenance, other than specialized welding or non-destructive testing, on the kinds of structures listed below, within the scope of work shown and subject to any further limitations specified in the maintenance policy manual.

Rating	Scope of work	Effective Date
Sheet Metal Structures	As specified in company manual	2018-11-29

Issued: 2018-11-29

Signed:



Darrell Thody
For the Minister of Transport

Supersedes certificate dated:

Canada



Transport
Canada
Civil Aviation

Transports
Canada
Aviation Civile

Your file Votre référence

Z 5015-17956

Our file Notre référence

RDIMS #: 15156881

Transport Canada Centre
103-1785 Clearbrook Rd
Abbotsford BC V2T 5X5

April 05, 2019

Clearwater Defence System Corp.
Unit B101 - 27265 Gloucester Way
Langley, BC V4W 3Z8

Attention: Kelly Loewen

Subject: Approval of a Maintenance Policy Manual (MPM) supplement (Component rated)

Dear Sir,

Following a review of the elements contained in the referenced MPM supplement against the requirements of the current Agreement on Civil Aviation Safety between Canada and the European Union (EU), Transport Canada hereby confirms approval of your MPM supplement. Compliance with your MPM and this supplement allows for acceptance by the European Aviation Safety Agency (EASA) of maintenance performed on EU aeronautical products (component only) under the jurisdiction of EASA. This Approval does not exceed the scope of your current TCCA CAR 573 certificate.

Clearwater Defense System Corp.

EASA Part-145 Approval Reference number: EASA.145.7324 valid until surrendered, suspended, or revoked

Your MPM supplement reference: Revision Initial dated 02 January 2019 is hereby approved by Transport Canada.

If you have any questions contact the undersigned at 604 504-4677.

Sincerely,

Hugo Feunekes
Civil Aviation Safety Inspector
Airworthiness
Pacific Region
for the Minister of Transport

Canada



AGÊNCIA NACIONAL DE AVIAÇÃO CIVIL – BRASIL (BRAZILIAN CIVIL AVIATION AUTHORITY)

CERTIFICADO DE ACEITAÇÃO DE EMPRESA DE MANUTENÇÃO (MAINTENANCE ORGANIZATION ACCEPTANCE CERTIFICATE)

CAEM Nº1902-31/ANAC (MAINTENANCE ORGANIZATION ACCEPTANCE CERTIFICATE NR 1902-31/ANAC)

Considerando o estabelecido no parágrafo 145.53(b)-I do RBAC 145, este Certificado, emitido em favor de **CLEARWATER DEFENSE SYSTEMS CORP.**, cujas instalações estão localizadas na 27265 GLOUCESTER WAY - UNIT B101, LANGLEY, BC, CANADA V4W 3Z8, reconhece que essa Empresa, tendo cumprido os requisitos estabelecidos no Entendimento Técnico de Manutenção de Aviação entre a Diretoria de Aviação Civil do Departamento de Transporte do Canadá – TCCA e Agência Nacional de Aviação Civil do Brasil – ANAC, está autorizada a executar manutenção em produtos aeronáuticos brasileiros. *(According to RBAC 145 paragraph 145.53(b)-I, this Certificate is issued to CLEARWATER DEFENSE SYSTEMS CORP., , whose business address is 27265 GLOUCESTER WAY - UNIT B101, LANGLEY, BC, CANADA V4W 3Z8, upon finding that it complies with the requirements established in the Technical Arrangement on Aviation Maintenance between the Transport Canada Civil Aviation Directorate – TCCA and the Brazilian National Civil Aviation Agency – ANAC, acknowledges that this maintenance organization is authorized to perform maintenance on Brazilian aircrafts and components.)*

Em consonância com os requisitos do Entendimento Técnico, qualquer manutenção efetuada em aeronaves brasileiras deve ser realizada de acordo com os padrões e limitações estabelecidos pela Diretoria de Aviação Civil do Departamento de Transporte do Canadá – TCCA e com os requisitos do Entendimento Técnico. *(In keeping with the requirements of the Technical Arrangement, any maintenance performed on Brazilian aircraft and components shall be performed in accordance with the ratings and limitations established by the Transport Canada Civil Aviation Directorate – TCCA and the Technical Arrangement requirements.)*

Este Certificado é intransferível, e qualquer grande modificação nas facilidades básicas, ou no seu endereço, deverá ser imediatamente comunicada à Agência Nacional de Aviação Civil Brasileira – ANAC. *(This Certificate is not transferable, and any major change in the basic facilities, or in the location thereof, shall be immediately reported to the Brazilian National Civil Aviation Agency – ANAC).*

DURAÇÃO: Este Certificado é válido **até 28 de fevereiro de 2021** a menos que seja revogado, suspenso ou cassado, conforme Entendimento Técnico de Manutenção de Aviação entre TCCA e ANAC e RBAC 145. *(Expiration date: This Certificate shall continue in effect until February 28th, 2021, unless it is canceled, suspended or revoked, in accordance with Technical Arrangement on Aviation between TCCA and ANAC and RBAC 145.*

ROBSON RIBEIRO DA SILVA - Deputy Airworthiness Technical Manager of Rio de Janeiro

Documento assinado eletronicamente por **Robson Ribeiro da Silva, Especialista em Regulação de Aviação Civil**, em 02/03/2020, às 17:21, conforme horário oficial de Brasília, com fundamento no art. 6º,



§ 1º, do Decreto nº 8.539, de 8 de outubro de 2015.



A autenticidade deste documento pode ser conferida no site <http://sistemas.anac.gov.br/sei/autenticidade>, informando o código verificador **4030638** e o código CRC **2F031738**.

Referência: Processo nº 00065.006551/2020-84

SEI nº 4030638



Place de Ville, Tower C
330 Sparks Street (AART)
Ottawa, ON K1A 0N8
Canada

June 05, 2020

Subject: ANAC Acceptance of AMOs in Canada for maintenance on Brazilian aeronautical components/parts.

To whom it may concern,

The Brazilian National Civil Aviation Agency - ANAC recently evaluated Transport Canada Civil Aviation's (TCCA's) regulatory system related to the maintenance and certification of aeronautical products. Upon analysis of this evaluation and considering the discussions held in the on-site visits in Canada and Brazil, ANAC has acknowledged compatibility between TCCA and ANAC systems for the maintenance and certification of aeronautical products (except aircraft, engines and propellers).

ANAC regulation RBAC 43, section 43.17 addresses a regulatory provision to foreign Approved Maintenance Organizations (AMOs) not certified by ANAC to provide maintenance and a maintenance release to Brazilian aeronautical products provided the conditions in the section are met. This provision does not include aircraft, engines or propellers, however exception is given to aeronautical components and parts.

This regulatory provision applies even in the absence of an international agreement and does not require mutual consideration by other Civil Aviation Authorities (CAA) providing the authority of the AMO has a regulatory system related to aeronautical maintenance functions that is compatible with the ANAC system. The compatibility concept is evaluated by assessing some critical aspects of the authority, and the degree of similarity between the regulations related to maintenance and specifically the one that is addressed to the AMOs, and the ANAC regulation. When deemed compatible, ANAC may issue a public document, an Ordinance (called "Portaria" in Portuguese), to present to the regulated entities.

On April 30th, ANAC issued Ordinance (Portaria n°1146/2020) to inform the regulated entities about the compatibility of the systems for the aeronautical maintenance capabilities in line with the paragraph 43.17(b)-I (1) from RBAC 43. Based on this document, any Canadian AMO approved by TCCA can provide maintenance and a maintenance release to components and parts under the regulatory jurisdiction of ANAC, without holding an ANAC Certificate (CAEM). These AMOs will not be required to follow the provisions of the agreement TA-M/IP (including paying the fee) and can directly perform maintenance to Brazilian components/parts, limited to the TCCA scope of approval. AMOs providing maintenance to aircraft, engine and propellers still need to be certified and hold a CAEM.

If you have any questions regarding this letter please contact the undersigned.

Best Regards,

Dean Barrett
Program Manager, Operational Airworthiness, Standards Branch
Transport Canada Civil Aviation
dean.barrett@tc.gc.ca

UH/SH-60 Capabilities

UNIT	PART NUMBER	OEM	NSN	SERVICE
PRIMARY SERVO	70410-02820-053	274000-1027	1650-01-114-9538	REPAIR & OVERHAUL
PRIMARY SERVO	70410-02820-054	274000-1031	1650-01-143-1226	REPAIR & OVERHAUL
PRIMARY SERVO	70410-02820-055	274000-1035	1650-01-625-0164	REPAIR & OVERHAUL
PITCH TRIM ACTUATOR	70410-02561-105	A22785-1	1650-01-106-1957	REPAIR & OVERHAUL
PITCH TRIM ACTUATOR	70410-02561-112	A22785-2	1650-01-375-3160	REPAIR & OVERHAUL
TAIL ROTOR SERVO	70410-06520-045	2227000-13	1650-01-125-5430	REPAIR & OVERHAUL
TAIL ROTOR SERVO	70410-06520-046	2227000-15	1650-01-335-9729	REPAIR & OVERHAUL
TAIL ROTOR SERVO	70410-06520-048	2227000-17	1650-01-305-6954	REPAIR & OVERHAUL
MAIN ROTOR DAMPER	70106-08100-042	-	1650-01-074-1218	REPAIR & OVERHAUL
MAIN ROTOR DAMPER	70106-08100-043	-	1650-01-146-5259	REPAIR & OVERHAUL
MAIN ROTOR DAMPER	70106-08100-044	-	1650-01-285-3023	REPAIR & OVERHAUL
MAIN ROTOR DAMPER	70106-08100-046	-	1650-01-285-3024	REPAIR & OVERHAUL
DAMPER INDICATOR	70106-08006-044	-	6680-01-266-4506	REPAIR & OVERHAUL
ROLL SAS ACTUATOR	70410-02450-047	-	1680-01-159-4447	REPAIR & OVERHAUL
SAS ACTUATOR	70410-02500-048	-	1560-01-083-6813	REPAIR & OVERHAUL
SAS ACTUATOR	70410-02500-049	-	1560-01-129-1256	REPAIR & OVERHAUL
SAS ACTUATOR	70410-02500-050	-	-	REPAIR & OVERHAUL
COLLECTIVE BOOST SERVO	70410-02920-050	274600-1033	1650-01-106-1915	REPAIR & OVERHAUL
COLLECTIVE BOOST SERVO	70410-02920-053	274600-1045	1650-01-140-0967	REPAIR & OVERHAUL
YAW BOOST SERVO	70410-02910-065	274600-1047	1650-01-143-1227	REPAIR & OVERHAUL
COLLECTIVE BOOST SERVO	70410-02920-055	274600-1049	1650-01-624-9557	REPAIR & OVERHAUL
YAW BOOST SERVO	70410-02920-069	274600-1051	1650-01-624-9255	REPAIR & OVERHAUL
TRANSFER MODULE	70652-02415-042	60900-11	1650-01-162-5035	REPAIR & OVERHAUL
TRANSFER MODULE	70652-02415-102	60900-1	-	REPAIR & OVERHAUL
TRANSFER MODULE	70652-02415-103	60900-3	-	REPAIR & OVERHAUL
STABILATOR ACTUATOR	70400-06641-117	DL2155M20	1680-01-261-2044	REPAIR & OVERHAUL
TAIL LANDING GEAR	70250-13100-042	-	-	REPAIR & OVERHAUL
TAIL LANDING GEAR	70250-13100-043	-	-	REPAIR & OVERHAUL
TAIL LANDING GEAR	70250-13100-044	-	-	REPAIR & OVERHAUL
TAIL LANDING GEAR	70250-13100-046	-	1680-01-585-4305	REPAIR & OVERHAUL
FIXED LANDING GEAR T/R	70250-13103-041	-	1620-01-095-6992	REPAIR & OVERHAUL
FIXED LANDING GEAR T/R	70250-13103-042	-	1620-01-325-8223	REPAIR & OVERHAUL
FIXED LANDING GEAR T/R	70250-13103-043	-	1620-01-623-9230	REPAIR & OVERHAUL
TAIL SHOCK STRUT	70250-13101-041	-	1620-01-078-5697	REPAIR & OVERHAUL
TAIL SHOCK STRUT	70250-13101-042	-	1620-01-096-5573	REPAIR & OVERHAUL
TAIL SHOCK STRUT	70250-13101-043	-	1620-01-205-6136	REPAIR & OVERHAUL
TAIL SHOCK STRUT	70250-13101-044	-	1620-01-421-0890	REPAIR & OVERHAUL
TAIL SHOCK STRUT	70250-13101-046	-	-	REPAIR & OVERHAUL
ACCESSORY MODULE	70351-08080-043	-	1615-01-078-5718	REPAIR & OVERHAUL

UH/SH-60 Capabilities

UNIT	PART NUMBER	OEM	NSN	SERVICE
ACCESSORY MODULE	70351-08080-045	-	1615-01-383-8992	REPAIR & OVERHAUL
LH LANDING GEAR	70250-12050-045	-	-	REPAIR & OVERHAUL
LH LANDING GEAR	70250-12050-047	-	-	REPAIR & OVERHAUL
LH LANDING GEAR	70250-12050-052	-	1680-01-568-9192	REPAIR & OVERHAUL
LH LANDING GEAR	70250-22009-041	-	1620-01-624-2296	REPAIR & OVERHAUL
RH LANDING GEAR	70250-12050-046	-	-	REPAIR & OVERHAUL
RH LANDING GEAR	70250-12050-048	-	-	REPAIR & OVERHAUL
RH LANDING GEAR	70250-12050-049	-	-	REPAIR & OVERHAUL
RH LANDING GEAR	70250-12050-053	-	1680-01-568-9193	REPAIR & OVERHAUL
RH LANDING GEAR	70250-22009-042	-	1620-01-624-2306	REPAIR & OVERHAUL
FIXED LANDING GEAR M/R	70250-12051-045	-	1620-01-231-1831	REPAIR & OVERHAUL
FIXED LANDING GEAR M/R	70250-12051-046	-	1560-01-480-5013	REPAIR & OVERHAUL
FIXED LANDING GEAR M/R	70250-12051-048	-	1620-01-562-3238	REPAIR & OVERHAUL
FIXED LANDING GEAR M/R	70250-12051-049	-	1620-01-622-7368	REPAIR & OVERHAUL
INPUT MODULE	70351-08001-043	-	1615-01-074-1219	REPAIR & OVERHAUL
INPUT MODULE	70351-08001-045	-	1615-01-168-2984	REPAIR & OVERHAUL
INPUT MODULE	70351-08001-046	-	1615-01-230-6218	REPAIR & OVERHAUL
INPUT MODULE	70351-08001-047	-	1615-01-241-6110	REPAIR & OVERHAUL
INPUT MODULE	70351-08001-049	-	1615-01-353-3825	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-053	-	1615-01-076-1260	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-054	-	1615-01-105-1450	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-055	-	1615-01-129-7330	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-056	-	1615-01-105-8713	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-057	-	1615-01-134-7274	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-058	-	1615-01-128-1749	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-059	-	1615-01-145-3928	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-060	-	1615-01-168-2983	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-061	-	1615-01-284-6419	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-062	-	-	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-063	-	-	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-064	-	-	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-065	-	-	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-066	-	-	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-067	-	-	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-068	-	-	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-069	-	1615-01-316-2658	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-070	-	1615-01-316-2659	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-071	-	1615-01-375-5846	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-072	-	1615-01-375-5847	REPAIR & OVERHAUL

UH/SH-60 Capabilities

UNIT	PART NUMBER	OEM	NSN	SERVICE
MAIN GEARBOX MODULE	70351-08100-073	-	1615-01-413-7786	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-074	-	1615-01-415-8387	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-075	-	1615-01-503-3114	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-08100-076	-	1615-01-503-3315	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-48100-041	-	1615-01-305-2375	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-38100-042	-	1615-01-225-9749	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-38100-044	-	1615-01-276-4582	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-38100-046	-	1615-01-251-6534	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-38100-047	-	1615-01-289-4810	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-38100-048	-	1615-01-483-2438	REPAIR & OVERHAUL
MAIN GEARBOX MODULE	70351-38100-050	-	1615-01-534-8106	REPAIR & OVERHAUL
MAIN GEARBOX	70351-58100-046	-	1615-01-542-7514	REPAIR & OVERHAUL
M/R MAST ASSEMBLY	70351-08131-044	-	3040-01-080-5568	REPAIR & OVERHAUL
M/R MAST ASSEMBLY	70351-08131-045	-	3040-01-134-2508	REPAIR & OVERHAUL
M/R MAST ASSEMBLY	70351-08131-046	-	3040-01-188-8204	REPAIR & OVERHAUL
M/R MAST ASSEMBLY	70351-08131-047	-	3040-01-316-2582	REPAIR & OVERHAUL
M/R MAST ASSEMBLY	70351-08131-048	-	3040-01-415-8388	REPAIR & OVERHAUL
M/R MAST ASSEMBLY	70351-08131-103	-	3040-01-432-9275	REPAIR & OVERHAUL
M/R MAST ASSEMBLY	70351-08131-107	-	3040-01-432-9244	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	70357-06300-042	-	1615-01-074-5152	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	70357-06300-043	-	1615-01-201-5623	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	70357-06300-044	-	1680-01-492-1441	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	70358-06600-041	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	70358-06600-042	-	1615-01-102-6052	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	70358-06600-043	-	1615-01-105-1510	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	70358-06600-044	-	1615-01-280-4444	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	70358-06600-046	-	1615-01-376-5089	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	70358-06600-048	-	1615-01-545-0883	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	70358-26600-042	-	1615-01-158-5772	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	70358-26600-043	-	1615-01-201-5624	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	70358-26600-044	-	1615-01-291-7572	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	70358-26600-045	-	1615-01-372-5467	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	70358-26600-046	-	1615-01-483-2443	REPAIR & OVERHAUL
TAIL ROTOR ROD ASSEMBLY	70103-11005-045	-	1615-01-083-6828	REPAIR & OVERHAUL
TAIL ROTOR ROD ASSEMBLY	70103-11005-042	-	1680-01-189-8766	REPAIR & OVERHAUL
TAIL ROTOR ROD ASSEMBLY	70103-11005-043	-	1615-01-083-6828	REPAIR & OVERHAUL
TAIL ROTOR ROD ASSEMBLY	70103-11005-045	-	1615-01-417-1305	REPAIR & OVERHAUL
TAIL ROTOR OUTBOARD PLATE	70102-11101-042	-	1615-01-083-6812	REPAIR & OVERHAUL
TAIL ROTOR OUTBOARD PLATE	70102-11101-043	-	1615-01-185-4870	REPAIR & OVERHAUL

UH/SH-60 Capabilities

UNIT	PART NUMBER	OEM	NSN	SERVICE
MAIN ROTOR HUB	70103-08100-043	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-044	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-045	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-046	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-047	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-048	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-049	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-050	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-051	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-052	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-053	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-054	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-055	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08100-057	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08200-041	-	-	REPAIR & OVERHAUL
BIFILAR ASSEMBLY	70107-08400-042	-	1615-01-286-8847	REPAIR & OVERHAUL
BIFILAR ASSEMBLY	70107-08400-043	-	1615-01-244-4959	REPAIR & OVERHAUL
BIFILAR ASSEMBLY	70107-08400-044	-	1615-01-085-5315	REPAIR & OVERHAUL
BIFILAR ASSEMBLY	70107-08400-045	-	1615-01-108-7279	REPAIR & OVERHAUL
BIFILAR ASSEMBLY	70107-08400-046	-	1615-01-127-7388	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70070-10030-041	-	-	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70070-10030-042	-	1615-01-331-2480	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70070-10030-043	-	-	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70070-10030-044	-	1615-01-353-4884	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70070-10030-045	-	-	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70070-10030-046	-	1615-01-249-4107	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70070-10030-047	-	-	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70102-08200-041	-	-	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70102-08200-042	-	1615-01-209-1759	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70102-08200-043	-	-	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70102-08200-044	-	1615-01-214-6602	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70102-08200-046	-	1615-01-295-1174	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70102-08200-053	-	-	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70102-08200-054	-	1615-01-372-9604	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70102-08200-055	-	-	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70102-08200-056	-	1615-01-374-7203	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70102-08200-063	-	1615-01-370-4918	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70102-08200-068	-	1615-01-516-9100	REPAIR & OVERHAUL
SPINDLE ASSEMBLY	70102-08200-069	-	1615-01-442-6926	REPAIR & OVERHAUL

UH/SH-60 Capabilities

UNIT	PART NUMBER	OEM	NSN	SERVICE
SPINDLE ASSEMBLY	70102-08200-071	-	1615-01-555-5344	REPAIR & OVERHAUL
HUB ASSEMBLY	70103-08112-041	-	1615-01-096-5427	REPAIR & OVERHAUL
HUB ASSEMBLY	70103-08112-042	-	1615-01-432-9268	REPAIR & OVERHAUL
HUB ASSEMBLY	70103-08112-047	-	1615-01-450-4834	REPAIR & OVERHAUL
HUB ASSEMBLY	70103-08112-048	-	-	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	70104-08000-043	-	1615-01-432-9273	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	70104-08000-044	-	1615-01-385-6381	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	70104-08000-045	-	1615-01-105-8716	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	70104-08000-046	-	1560-01-106-1918	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	70104-08000-049	-	1615-01-210-4572	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	70104-08000-050	-	1615-01-199-7646	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	70104-08000-060	-	1615-01-558-9830	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	70104-08001-043	-	1615-01-075-5282	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	70104-08001-044	-	1615-01-081-9262	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	70104-08001-045	-	1615-01-357-5089	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	70104-08001-046	-	1615-01-357-5089	REPAIR & OVERHAUL
SWASHPLATE & SCISSORS	70104-08020-043	-	1615-01-075-5282	REPAIR & OVERHAUL
SWASHPLATE & SCISSORS	70104-08020-044	-	1615-01-491-9051	REPAIR & OVERHAUL
SWASHPLATE & SCISSORS	70104-08020-045	-	1615-01-105-8716	REPAIR & OVERHAUL
SWASHPLATE & SCISSORS	70104-08020-046	-	1615-01-159-4708	REPAIR & OVERHAUL
SWASHPLATE & SCISSORS	70104-08020-047	-	1615-01-553-3949	REPAIR & OVERHAUL
LINK ASSEMBLY	70104-08021-041	-	1615-01-089-0439	REPAIR & OVERHAUL
LINK ASSEMBLY	70104-08021-043	-	1615-01-169-0863	REPAIR & OVERHAUL
LINK ASSEMBLY	70104-08021-046	-	3040-01-545-6083	REPAIR & OVERHAUL
UTILITY PUMP MODULE	70652-02300-048	53023-03	4320-01-092-6724	REPAIR & OVERHAUL
UTILITY PUMP MODULE	70652-02300-049	53023-05	4320-01-136-2118	REPAIR & OVERHAUL
UTILITY PUMP MODULE	70652-02300-050	53023-06	4320-01-207-7228	REPAIR & OVERHAUL
UTILITY PUMP MODULE	-	53023-07	-	REPAIR & OVERHAUL
VANEAXIAL FAN	70361-03005-103	83D93-2K	4140-01-138-6950	REPAIR & OVERHAUL
VANEAXIAL FAN	70361-03005-104	83D93-9	4140-01-158-9515	REPAIR & OVERHAUL
VANEAXIAL FAN	70361-03005-105	83D93-8	4140-01-089-0465	REPAIR & OVERHAUL
VANEAXIAL FAN	70361-03005-106	83D93-10	4140-01-266-4519	REPAIR & OVERHAUL
VANEAXIAL FAN	70361-03005-107	52E15-1	4140-01-329-3428	REPAIR & OVERHAUL
VANEAXIAL FAN	70361-03700-101	83D93-9	4140-01-266-4518	REPAIR & OVERHAUL
YOKE ASSEMBLY	70250-13158-042	-	1620-01-082-0688	REPAIR & OVERHAUL
YOKE ASSEMBLY	70250-13158-043	-	1620-01-375-8565	REPAIR & OVERHAUL
DRAG BRACE	70250-22010-041	-	1620-01-611-8100	REPAIR & OVERHAUL
DRAG BRACE	70250-22010-042	-	1620-01-612-0355	REPAIR & OVERHAUL
CARGO HOOK	70800-02503-103	FE7590-55	4030-01-109-3024	REPAIR & OVERHAUL

UH/SH-60 Capabilities

UNIT	PART NUMBER	OEM	NSN	SERVICE
CARGO HOOK	70800-02503-105	FE7590-120	4030-01-271-6239	REPAIR & OVERHAUL
CARGO HOOK	70800-02503-107	FE7590-120A	4030-01-176-9353	REPAIR & OVERHAUL
CARGO HOOK	70800-02503-145	FE7590-145	4030-01-238-4394	REPAIR & OVERHAUL
CARGO HOOK	70800-02503-113	FE7590-173	4030-01-456-4792	REPAIR & OVERHAUL
LEFT TIE ROD	70400-08115-046	-	1560-01-289-2697	REPAIR & OVERHAUL
FWD BELLCRANK SUPPORT	70400-08162-042	-	1560-01-221-2619	REPAIR & OVERHAUL
ROTATING EYE BRACKET	70103-08103-045	-	3040-01-134-8362	REPAIR & OVERHAUL
STABILATOR FITTING	70209-07051-050	-	1560-01-081-9253	REPAIR & OVERHAUL
STABILATOR FITTING	70209-07051-051	-	-	REPAIR & OVERHAUL
STABILATOR FITTING	70209-07051-052	-	1560-01-088-1709	REPAIR & OVERHAUL
PILOT ASSIST MODULE	70652-02620-044	-	-	REPAIR & OVERHAUL
PILOT ASSIST MODULE	70652-02620-046	-	1560-01-106-1905	REPAIR & OVERHAUL
SERVO COUPLING	70400-06100-041	-	1615-01-092-2004	REPAIR & OVERHAUL
SERVO COUPLING	70400-06100-042	-	1615-01-141-7532	REPAIR & OVERHAUL
STABILATOR L/H	70200-07801-101	-	1560-01-542-7904	REPAIR & OVERHAUL
STABILATOR L/H	70200-27000-047	-	1560-01-617-5074	REPAIR & OVERHAUL
STABILATOR R/H	70200-07801-102	-	1560-01-542-8455	REPAIR & OVERHAUL
STABILATOR R/H	70200-27000-048	-	1560-01-553-3768	REPAIR & OVERHAUL
ACCUMULATOR	70651-03201-105	-	1650-01-222-4316	REPAIR & OVERHAUL
ACCUMULATOR	70651-03201-104	-	1650-01-250-3767	REPAIR & OVERHAUL
TAIL PYLON ASSEMBLY	70200-56050-042	-	-	REPAIR & OVERHAUL
TAIL PYLON ASSEMBLY	70200-06050-043	-	-	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10300-041	-	-	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10300-042	-	-	REPAIR & OVERHAUL
BRAKE ASSEMBLY	70250-12060-102	-	-	REPAIR & OVERHAUL
CONNECTING LINK	70400-08151-061	-	3040-01-287-2438	REPAIR & OVERHAUL
CONNECTING LINK	70400-08110-061	-	3040-01-285-3018	REPAIR & OVERHAUL
FLIGHT CONTROL MIXER	70400-02300-041	-	5120-01-161-3979	REPAIR & OVERHAUL
FLIGHT CONTROL MIXER	70400-02300-043	-	1615-01-378-4429	REPAIR & OVERHAUL
FLIGHT CONTROL MIXER	70400-02300-044	-	1615-01-074-1223	REPAIR & OVERHAUL
FLIGHT CONTROL MIXER	70400-02300-045	-	1615-01-202-3321	REPAIR & OVERHAUL
FLIGHT CONTROL MIXER	70400-02300-046	-	1615-01-260-0749	REPAIR & OVERHAUL
FLIGHT CONTROL MIXER	70400-02300-048	-	1680-01-310-2259	REPAIR & OVERHAUL
BELLCRANK SUPPORT	70400-08163-043	-	3040-01-325-7874	REPAIR & OVERHAUL
COUPLING	70358-06304-042	-	3040-01-085-6720	REPAIR & OVERHAUL
YAW BOOST SERVO	70410-02910-067	-	1650-01-136-5496	REPAIR & OVERHAUL
MAIN ROTOR BLADE	70150-09100-041	-	1615-01-074-5150	REPAIR & OVERHAUL
MAIN ROTOR BLADE	70150-09100-043	-	1615-01-106-1903	REPAIR & OVERHAUL
MAIN ROTOR BLADE	70150-09200-041	-	1615-01-546-1148	REPAIR & OVERHAUL

UH/SH-60 Capabilities

UNIT	PART NUMBER	OEM	NSN	SERVICE
TAIL ROTOR BLADE	70101-31000-043	-	1615-01-113-8188	REPAIR & OVERHAUL
PRIMARY SERVO	70410-22820-043	-	6615-01-158-5984	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10300-066	-	-	REPAIR & OVERHAUL
INDICATOR PANEL	622-601530-000	-	1680-01-328-6570	REPAIR & OVERHAUL
FRAME FITTING RH	70209-06052-046	-	-	REPAIR & OVERHAUL
FRAME FITTING LH	70209-06052-041	-	-	REPAIR & OVERHAUL
GYRO	46060-3	-	6615-00-453-5670	REPAIR & OVERHAUL
ALTIMETER	10450-31327	-	6610-01-091-3702	REPAIR & OVERHAUL
HORIZONTAL STABILIZER	70200-07050-043	-	1560-01-082-6492	REPAIR & OVERHAUL
HORIZONTAL STABILIZER	70200-07050-044	-	1560-01-125-0795	REPAIR & OVERHAUL
HORIZONTAL STABILIZER	70200-07050-047	-	1560-01-214-0192	REPAIR & OVERHAUL
HORIZONTAL STABILIZER	70200-07050-051	-	1560-01-301-8212	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-061	-	2815-01-491-1828	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-062	-	-	REPAIR & OVERHAUL
SWASHPLATE SUPPORT	70400-08165-043	-	-	REPAIR & OVERHAUL
BELL CRANK	70400-08101-046	-	1680-01-158-9652	REPAIR & OVERHAUL
WALKING BEAM SERVO	70400-08104-048	-	1680-01-158-9653	REPAIR & OVERHAUL
BELLCRANK SUPPORT	70400-08162-045	-	1560-01-450-4841	REPAIR & OVERHAUL
BELLCRANK SUPPORT	70400-08162-046	-	-	REPAIR & OVERHAUL
BELLCRANK SUPPORT	70400-08116-048	-	1560-01-158-9656	REPAIR & OVERHAUL
EXTENSION ASSEMBLY	70351-08186-043	-	-	REPAIR & OVERHAUL
RETENTION PLATE	70358-06612-042	-	1615-01-074-5153	REPAIR & OVERHAUL
TRANSFER MODULE	70652-02455-046	-	1650-01-113-8172	REPAIR & OVERHAUL
TRANSFER MODULE	70652-02455-047	-	1650-01-105-1529	REPAIR & OVERHAUL
CENTER STABILATOR	70200-27000-049	-	1560-01-294-7824	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10300-058	-	-	REPAIR & OVERHAUL
TIP CAP	70150-09207-041	-	1560-01-447-9774	REPAIR & OVERHAUL
RESCUE HOIST	BL-29900-30-1	-	1680-01-505-3913	REPAIR & OVERHAUL
STARTER GENERATOR	3505300-9-1	-	1680-01-501-4998	REPAIR & OVERHAUL
STARTER GENERATOR	3505300-9-6	-	-	REPAIR & OVERHAUL
BELL CRANK	70400-08102-045	-	1560-01-158-9685	REPAIR & OVERHAUL
PRIMARY SERVO	70410-22820-043	274000-1033	6615-01-158-5984	REPAIR & OVERHAUL
EMERGENCY POWER SUPPLY	70600-01822-104	-	6130-01-558-4798	REPAIR & OVERHAUL
MAIN ROTOR HUB	70103-08112-051	-	1615-01-640-8429	REPAIR & OVERHAUL
DRAG BRACE	70250-22010-043	-	1620-01-523-0905	REPAIR & OVERHAUL
EXTENSION ASSEMBLY	70351-08186-047	-	1615-01-634-0170	REPAIR & OVERHAUL
PEDAL ADJUSTER	70400-21613-043	-	1680-01-159-4583	REPAIR & OVERHAUL
PEDAL ADJUSTER	70400-21613-044	-	1680-01-159-4584	REPAIR & OVERHAUL
PEDAL ADJUSTER	70400-01613-052	-	1680-01-092-1985	REPAIR & OVERHAUL

UH/SH-60 Capabilities

UNIT	PART NUMBER	OEM	NSN	SERVICE
PEDAL ADJUSTER	70103-08010-048	-	5340-01-105-1509	REPAIR & OVERHAUL
PEDAL ADJUSTER	70103-08010-050	-	5340-01-332-9374	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-042	-	-	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-046	-	-	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-048	-	1560-01-114-9520	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-050	-	-	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-047	-	-	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-049	-	-	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-051	-	1560-01-127-7387	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-053	-	-	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-054	-	-	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-055	-	-	REPAIR & OVERHAUL
INLET ASSEMBLY	70302-10100-058	-	1560-01-319-1209	REPAIR & OVERHAUL
QUADRANT ASSEMBLY	70301-01033-041	-	-	REPAIR & OVERHAUL
QUADRANT ASSEMBLY	70301-01033-042	-	1680-01-242-9186	REPAIR & OVERHAUL
QUADRANT ASSEMBLY	70301-01033-043	-	1680-01-123-2555	REPAIR & OVERHAUL
QUADRANT ASSEMBLY	70301-01033-044	-	1680-01-123-2539	REPAIR & OVERHAUL
QUADRANT ASSEMBLY	70301-01033-045	-	1680-01-242-9185	REPAIR & OVERHAUL
QUADRANT ASSEMBLY	70301-01033-046	-	1680-01-242-9186	REPAIR & OVERHAUL
ACCESS COVER	70217-01003-047	-	5340-01-095-7565	REPAIR & OVERHAUL
ACCESS COVER	70217-01003-048	-	1560-01-123-2584	REPAIR & OVERHAUL
EXTENSION ASSEMBLY	70351-08186-044	-	1615-01-432-9972	REPAIR & OVERHAUL
MAIN ROTOR HEAD	70103-08200-056	-	-	REPAIR & OVERHAUL
FAIRING	70205-06051-011	-	-	REPAIR & OVERHAUL
FAIRING	70205-06051-012	-	-	REPAIR & OVERHAUL
FAIRING	70205-06051-043	-	1615-01-137-3517	REPAIR & OVERHAUL
CONNECTING LINK	70101-08000-046	-	3040-01-084-5516	REPAIR & OVERHAUL
CONNECTING LINK	70101-08000-048	-	3040-01-417-0132	REPAIR & OVERHAUL
NUT ASSEMBLY	70103-08005-104	-	1615-01-240-1569	REPAIR & OVERHAUL
QUADRANT ASSEMBLY	70400-06690-041	-	-	REPAIR & OVERHAUL
QUADRANT ASSEMBLY	70400-06690-044	-	1615-01-175-8943	REPAIR & OVERHAUL
ROD ASSEMBLY	70400-06698-047	-	1680-01-153-2286	REPAIR & OVERHAUL
BEAM ASSEMBLY	70103-11001-041	-	1615-01-086-1498	REPAIR & OVERHAUL
ROD ASSEMBLY	70103-11005-045	-	1615-01-417-1305	REPAIR & OVERHAUL
TAIL PYLON COVER	70205-06058-011	-	-	REPAIR & OVERHAUL
TAIL STRUCTURAL ASSY	70200-56150-042	-	-	REPAIR & OVERHAUL
TAIL ROTOR PYLON	70001-06100-042	-	-	REPAIR & OVERHAUL
STRUCTURAL PANEL	70205-06052-071	-	1560-01-578-8444	REPAIR & OVERHAUL
AIRCRAFT FAIRING	70205-06052-070	-	1560-01-582-6316	REPAIR & OVERHAUL

UH/SH-60 Capabilities

UNIT	PART NUMBER	OEM	NSN	SERVICE
TAIL CAMBERED FAIRING	70205-56054-011	-	-	REPAIR & OVERHAUL
TAIL PYLON FAIRING INSTL	71205-85606-012	-	-	REPAIR & OVERHAUL
FAIRING ASSY	70215-05001-011	-	-	REPAIR & OVERHAUL
FAIRING ASSY	70215-05001-056	-	-	REPAIR & OVERHAUL
STABILATOR	70200-27000-046	-	1560-01-222-5123	REPAIR & OVERHAUL
TAIL L/G FORK ASSEMBLY	70250-13158-043	-	1620-01-375-8565	REPAIR & OVERHAUL
PEDAL ADJUSTER	70400-21613-041	-	5120-01-522-7060	REPAIR & OVERHAUL
PEDAL ADJUSTER	70400-21613-052	-	-	REPAIR & OVERHAUL
PITCH HORN ASSEMBLY	70102-08111-046	-	1615-01-433-0000	REPAIR & OVERHAUL
PITCH HORN ASSEMBLY	70102-08111-047	-	1615-01-214-9140	REPAIR & OVERHAUL
MAIN ROTOR SPINDLE	70102-28100-044	-	1615-01-563-9201	REPAIR & OVERHAUL
MAIN ROTOR SPINDLE	70102-28100-047	-	1615-01-238-2446	REPAIR & OVERHAUL
BELL CRANK	70400-08166-041	-	1680-01-221-2863	REPAIR & OVERHAUL
MAIN ROTOR DAMPER	70106-28000-047	-	1615-01-293-8020	REPAIR & OVERHAUL
MAIN ROTOR DAMPER	70106-28000-048	-	1615-01-347-0735	REPAIR & OVERHAUL
MAIN ROTOR DAMPER	70106-28000-049	-	1615-01-604-7562	REPAIR & OVERHAUL
MASTER BRAKE CYLINDER	70651-21110-104	-	1630-01-161-4419	REPAIR & OVERHAUL
ENGINE CONTROL INPUT ASSY	70301-02110-041	-	1560-01-078-5726	REPAIR & OVERHAUL
ENGINE CONTROL INPUT ASSY	70301-02110-042	-	1560-01-078-5725	REPAIR & OVERHAUL



CH-47 Capabilities

UNIT	PART NUMBER	OEM	NSN	SERVICE
VANAXIAL FAN	145DS210-5	-	4140-01-113-0272	REPAIR & OVERHAUL
ACCUMULATOR	145HS654-7	898254-1	1650-01-116-2999	REPAIR & OVERHAUL
ACCUMULATOR	145HS654-7	28-60003-3	1650-01-246-9554	REPAIR & OVERHAUL
FORWARD HEAD ASSEMBLY	145R2003-9	-	1615-01-314-8863	REPAIR & OVERHAUL
FORWARD HEAD ASSEMBLY	145R2003-10	-	1615-01-391-4398	REPAIR & OVERHAUL
AFT HEAD ASSEMBLY	145R2004-18	-	1615-01-315-3972	REPAIR & OVERHAUL
AFT HEAD ASSEMBLY	145R2004-20	-	1615-01-391-4399	REPAIR & OVERHAUL
FWD/AFT SWASHPLATE ASSY	145R3551-19	-	1615-01-473-4376	REPAIR & OVERHAUL
FWD/AFT SWASHPLATE ASSY	145R3551-20	-	1615-01-475-9838	REPAIR & OVERHAUL
PIVOTING DUAL ACTUATING SERVO	145H6600-19	-	1650-01-304-9016	REPAIR & OVERHAUL
PIVOTING DUAL ACTUATING SERVO	145H6600-20	-	1650-01-303-7897	REPAIR & OVERHAUL
SWIVELING DUAL ACTUATING SERVO	145H6700-18	-	1650-01-303-7898	REPAIR & OVERHAUL
SWIVELING DUAL ACTUATING SERVO	145H6700-19	-	1650-01-302-0076	REPAIR & OVERHAUL
LANDING GEAR	70250-12051-042	-	1620-01-109-7195	REPAIR & OVERHAUL
LANDING GEAR	70250-12051-043	-	1620-01-111-0193	REPAIR & OVERHAUL
LANDING GEAR	70250-12051-044	-	1620-01-181-8288	REPAIR & OVERHAUL
FWD SHOCK STRUT	114L1010-7	-	1620-00-868-5761	REPAIR & OVERHAUL
FWD SHOCK STRUT	114L1010-8	-	1620-00-868-5761	REPAIR & OVERHAUL
AFT SHOCK STRUT	114L2331-2	-	1620-00-869-2418	REPAIR & OVERHAUL
RAMP ACTUATING CYLINDER	70652-02455-046	-	1650-01-113-8172	REPAIR & OVERHAUL
RAMP ACTUATING CYLINDER	70652-02455-047	-	1650-01-105-1529	REPAIR & OVERHAUL
PITCH TRIM ACTUATOR	70410-02561-112	A22785-2	1650-01-375-3160	REPAIR & OVERHAUL
SHROUD DIFFUSER & IMPELLER	145DS106-7	723104A	1615-01-113-0222	REPAIR & OVERHAUL
SHROUD DIFFUSER & IMPELLER	145DS106-8	723102A	1615-01-113-0223	REPAIR & OVERHAUL
SHROUD DIFFUSER & IMPELLER	145DS106-9	730737	1615-01-113-0224	REPAIR & OVERHAUL
SHROUD DIFFUSER & IMPELLER	145DS106-11	40926-1	4140-01-326-0723	REPAIR & OVERHAUL
SHROUD DIFFUSER & IMPELLER	145DS106-12	40927-1	1660-01-325-9843	REPAIR & OVERHAUL
SHROUD DIFFUSER & IMPELLER	145DS106-13	40928-1	4140-01-326-0722	REPAIR & OVERHAUL
ADAPTER ASSEMBLY	145D3407-6	-	1615-01-113-0249	REPAIR & OVERHAUL
ADAPTER ASSEMBLY	145D3407-7	-	1615-01-140-6703	REPAIR & OVERHAUL
ADAPTER ASSEMBLY	145D3407-8	-	1615-01-119-3360	REPAIR & OVERHAUL
ADAPTER ASSEMBLY	145D3407-9	-	1615-01-114-0845	REPAIR & OVERHAUL
ADAPTER ASSEMBLY	145D3500-16	-	1615-01-319-5091	REPAIR & OVERHAUL
ADAPTER ASSEMBLY	145D3500-17	-	1615-01-319-5092	REPAIR & OVERHAUL
DAMPER	114H6800-11	-	1650-01-371-2475	REPAIR & OVERHAUL
FWD/AFT COVER ASSEMBLY	414R6001-1	-	1615-01-115-3615	REPAIR & OVERHAUL
FWD/AFT COVER ASSEMBLY	414R6001-2	-	1615-01-117-1121	REPAIR & OVERHAUL
CYLINDER ASSEMBLY	114HS105-6	18050-10	1630-00-056-2329	REPAIR & OVERHAUL
LINK ASSEMBLY	414C3056-4	-	1615-01-117-1136	REPAIR & OVERHAUL

CH-47 Capabilities

UNIT	PART NUMBER	OEM	NSN	SERVICE
YOKE ASSEMBLY	145C3050-3	-	1560-01-116-4203	REPAIR & OVERHAUL
CONNECTING LINK	145C3340-10	-	3040-01-117-7361	REPAIR & OVERHAUL
BELL CRANK	145C3230-1	-	1680-01-116-4313	REPAIR & OVERHAUL
BELL CRANK	145C3231-1	-	1680-01-116-4315	REPAIR & OVERHAUL
BELL CRANK	145C3221-1	-	1680-01-116-4314	REPAIR & OVERHAUL
BELL CRANK	145C3317-3	-	3040-01-117-1080	REPAIR & OVERHAUL
BELL CRANK	145C3122-1	-	1680-01-116-4309	REPAIR & OVERHAUL
BELL CRANK	145C3171-3	-	1680-01-193-4765	REPAIR & OVERHAUL
BELL CRANK	145C3172-3	-	1680-01-193-4766	REPAIR & OVERHAUL
BELL CRANK	145C3110-1	-	1680-01-116-4311	REPAIR & OVERHAUL
BELL CRANK	145C3311-3	-	1680-01-499-6225	REPAIR & OVERHAUL
BELL CRANK	145C3316-20	-	-	REPAIR & OVERHAUL
CONNECTING LINK	114C3327-24	-	3040-00-181-2974	REPAIR & OVERHAUL
BELL CRANK	114C3319-20	-	1680-01-611-6097	REPAIR & OVERHAUL
BELL CRANK	114C3318-20	-	1560-00-789-7783	REPAIR & OVERHAUL
BELL CRANK	114C3320-22	-	1680-00-789-4951	REPAIR & OVERHAUL
BELL CRANK	114C3324-6	-	1560-00-789-4950	REPAIR & OVERHAUL
BELL CRANK	114C3325-22	-	1680-00-789-4977	REPAIR & OVERHAUL
CONNECTING LINK	145CS340-15	-	3040-01-308-7097	REPAIR & OVERHAUL
CONNECTING LINK	145CS340-9	-	3040-01-309-7297	REPAIR & OVERHAUL
CONTROL ARM	414C3409-1	-	1560-01-114-0936	REPAIR & OVERHAUL
CONTROL ARM	414C3410-1	-	-	REPAIR & OVERHAUL
PYLON SUPPORT ASSEMBLY	145C3266-1	-	1560-01-116-4204	REPAIR & OVERHAUL
LINEAR ACTUATOR	541604-3-1	-	1680-00-103-0029	REPAIR & OVERHAUL
LINEAR ACTUATOR	541604-4-1	-	1680-00-117-9484	REPAIR & OVERHAUL
LINEAR ACTUATOR	541604-8-1	-	1680-01-120-7642	REPAIR & OVERHAUL
LINEAR ACTUATOR	541604-9-1	-	1680-01-120-7641	REPAIR & OVERHAUL
LINEAR ACTUATOR	114CS114-24	-	1680-00-103-0029	REPAIR & OVERHAUL
LINEAR ACTUATOR	114CS114-26	-	1680-00-117-9484	REPAIR & OVERHAUL
LINEAR ACTUATOR	114CS114-1	-	1680-00-132-1026	REPAIR & OVERHAUL
LINEAR ACTUATOR	114CS114-2	-	1680-00-132-1025	REPAIR & OVERHAUL



AH-1 Helicopter

UNIT	PART NUMBER	OEM	NSN	SERVICE
MAIN ROTOR HUB ASSEMBLY	540-011-101-5	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	540-011-101-9	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	540-011-101-17	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	540-011-101-23	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	540-011-101-25	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	540-011-101-129	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	540-011-101-131	-	-	REPAIR & OVERHAUL
SCISSOR AND SLEEVE	209-010-401-1	-	-	REPAIR & OVERHAUL
SCISSOR AND SLEEVE	209-010-401-3	-	-	REPAIR & OVERHAUL
SCISSOR AND SLEEVE	209-010-401-5	-	-	REPAIR & OVERHAUL
SCISSOR AND SLEEVE	209-010-401-11	-	-	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	209-011-400-1	-	-	REPAIR & OVERHAUL
MAST ASSEMBLY	209-040-366-1	-	-	REPAIR & OVERHAUL
MAST ASSEMBLY	209-040-366-3	-	-	REPAIR & OVERHAUL
MAST ASSEMBLY	209-040-366-5	-	-	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	209-961-400-3	-	-	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	212-040-001-39	-	-	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	212-040-001-51	-	-	REPAIR & OVERHAUL
MAIN INPUT QUILL	205-040-263-3	-	-	REPAIR & OVERHAUL
MAIN INPUT QUILL	205-040-263-111	-	-	REPAIR & OVERHAUL
HYDRAULIC PUMP QUILL	212-040-365-33	-	-	REPAIR & OVERHAUL
MAIN DRIVESHAFT ASSEMBLY	204-040-433-101	-	-	REPAIR & OVERHAUL
MAIN DRIVESHAFT ASSEMBLY	SKCP 2381-1	-	-	REPAIR & OVERHAUL
TAIL HANGER ASSEMBLY	212-040-600-1	-	-	REPAIR & OVERHAUL
TAIL HANGER ASSEMBLY	212-040-600-5	-	-	REPAIR & OVERHAUL
TAIL HANGER ASSEMBLY	212-040-600-9	-	-	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	212-040-003-23	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	212-040-004-9	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	212-010-701-3	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	212-010-701-31	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	212-010-701-35	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	212-010-701-139	-	-	REPAIR & OVERHAUL
MASTER CYLINDER ASSEMBLY	204-076-036-005	-	-	REPAIR & OVERHAUL
MAIN ROTOR SERVO	214-076-010-103	-	-	REPAIR & OVERHAUL
MAIN ROTOR SERVO	214-076-010-105	-	-	REPAIR & OVERHAUL

OH58 Helicopter

UNIT	PART NUMBER	OEM	NSN	SERVICE
MAIN ROTOR HUB ASSEMBLY	206-010-100-131	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	206-010-100-143	-	-	REPAIR & OVERHAUL
MAST ASSEMBLY	206-040-003-7	-	1615-00-178-8419	REPAIR & OVERHAUL
MAST ASSEMBLY	206-040-003-25	-	1615-01-036-4590	REPAIR & OVERHAUL
SWASHPLATE & SUPPORT	206-010-450-7	-	1615-01-062-6317	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	206-040-003-5	-	1615-00-121-6543	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	206-040-003-23	-	1615-01-034-0405	REPAIR & OVERHAUL
FREEWHEEL ASSEMBLY	206-040-230-25	-	1615-01-039-4400	REPAIR & OVERHAUL
FREEWHEEL ASSEMBLY	206-040-270-3	-	-	REPAIR & OVERHAUL
MAIN DRIVESHAFT ASSEMBLY	206-040-100-13	-	1615-00-120-0491	REPAIR & OVERHAUL
MAIN DRIVESHAFT ASSEMBLY	SKCP 2348-5	-	1615-01-268-5777	REPAIR & OVERHAUL
OIL COOLER BLOWER	206-061-432-1	-	1615-00-169-0360	REPAIR & OVERHAUL
OIL COOLER BLOWER	206-061-432-39	-	1615-01-034-0973	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	206-040-400-9	-	1615-00-432-2492	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	206-040-402-3	-	1615-01-214-9167	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	206-011-801-7	-	1615-00-121-6354	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	206-011-801-115	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	206-011-810-125	-	1615-21-899-6083	REPAIR & OVERHAUL



B204 - B205 Series

UNIT	PART NUMBER	OEM	NSN	SERVICE
STABILIZER BAR ASSEMBLY	204-011-326-ALL	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	204-012-101-ALL	-	-	REPAIR & OVERHAUL
SCISSOR & SLEEVE ASSEMBLY	204-011-401-ALL	-	-	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	204-011-400-ALL	-	-	REPAIR & OVERHAUL
MAST ASSEMBLY	204-040-366-ALL	-	-	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	204-040-009-ALL	-	-	REPAIR & OVERHAUL
MAIN DRIVESHAFT ASSEMBLY	201-040-010-007	-	-	REPAIR & OVERHAUL
TAIL HANGER ASSEMBLY	204-040-600-ALL	-	-	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	204-040-003-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	204-040-012-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	204-011-801-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB & BLADE	204-011-800-ALL	-	-	REPAIR & OVERHAUL
MASTER CYLINDER ASSEMBLY	204-076-036-005	-	-	REPAIR & OVERHAUL
MAIN ROTOR SERVO	205-076-030-001	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	205-076-029-011	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	205-076-031-003	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	205-076-036-105	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	205-076-036-107	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	205-076-056-107	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	41000970-001	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	205-076-500-001	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	205-076-055-101	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	205-076-038-007	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	SGT 220-1	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	SGT 220-3	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	SGT 220-5	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	SGT 220-7	-	-	REPAIR & OVERHAUL
MAIN ROTO SERVO	SGT 220-11	-	-	REPAIR & OVERHAUL
STABILIZER BAR ASSEMBLY	212-010-300-ALL	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	204-012-101-ALL	-	-	REPAIR & OVERHAUL
SCISSOR & SLEEVE ASSEMBLY	204-011-401-ALL	-	-	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	204-011-400-ALL	-	-	REPAIR & OVERHAUL
MAST ASSEMBLY	204-040-366-ALL	-	-	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	205-040-001-ALL	-	-	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	212-040-001	-	-	REPAIR & OVERHAUL
MAIN DRIVESHAFT ASSEMBLY	205-040-004-ALL	-	-	REPAIR & OVERHAUL

B204 - B205 Series

UNIT	PART NUMBER	OEM	NSN	SERVICE
MAIN DRIVESHAFT ASSEMBLY	204-040-433-101	-	1615-01-235-7920	REPAIR & OVERHAUL
TAIL HANGER ASSEMBLY	212-040-600-ALL	-	-	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	212-040-003-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	212-040-004-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	212-010-701-ALL	-	-	REPAIR & OVERHAUL
ROTOR BRAKE QUILL	412-040-123-101	-	4820-01-362-8610	REPAIR & OVERHAUL
ROTOR BRAKE CALIPER	9450103-1	-	1630-00-410-9397	REPAIR & OVERHAUL
ROTOR BRAKE DISC	9440791-1	-	1630-01-047-7335	REPAIR & OVERHAUL
MASTER CYLINDER ASSEMBLY	204-076-036-005	-	1630-00-222-1065	REPAIR & OVERHAUL
STABILIZER BAR ASSEMBLY	201-011-326-7	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	204-01-101-5	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	204-01-101-19	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	204-01-101-31	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	204-01-101-137	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	204-01-101-139	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	204-01-101-141	-	-	REPAIR & OVERHAUL
SCISSOR & SLEEVE ASSEMBLY	204-011-401-9	-	1615-00-957-7316	REPAIR & OVERHAUL
SCISSOR & SLEEVE ASSEMBLY	204-011-401-11	-	1615-00-454-8828	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	204-011-400-11	-	1615-00-060-1062	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	204-011-400-13	-	1615-00-255-2900	REPAIR & OVERHAUL
MAST ASSEMBLY	204-040-366-7	-	-	REPAIR & OVERHAUL
MAST ASSEMBLY	204-040-366-15	-	1615-00-255-2896	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	204-040-016-1	-	1680-00-089-6509	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	204-04-016-3	-	-	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	204-04-016-5	-	-	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	205-040-001-17	-	1615-00-919-1351	REPAIR & OVERHAUL
MAIN DRIVESHAFT ASSEMBLY	205-040-004-21	-	1615-01-014-6005	REPAIR & OVERHAUL
MAIN DRIVESHAFT ASSEMBLY	SKCP2281-103	-	1615-01-072-5670	REPAIR & OVERHAUL
MAIN INPUT QUILL	205-040-263-3	-	1615-00-134-3087	REPAIR & OVERHAUL
MAIN INPUT QUILL	205-040-263-111	-	1615-01-112-5904	REPAIR & OVERHAUL
TAIL HANGER ASSEMBLY	204-040-600-1	-	-	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	204-040-003-13	-	1615-00-633-0864	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	204-040-003-23	-	1615-00-776-1626	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	204-040-003-29	-	1615-00-472-7306	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	204-040-003-37	-	1615-00-918-2676	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	204-040-012-13	-	3040-00-918-2677	REPAIR & OVERHAUL



t | T 604.746.1133 | f 604.746.1152
a | 27265 Gloucester Way – Unit B101, Langley, BC V4W 3Z8
w | www.cwdsys.com

B204 - B205 Series

UNIT	PART NUMBER	OEM	NSN	SERVICE
TAIL ROTOR HUB ASSEMBLY	204-011-801-17	-	1615-00-133-6872	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	204-011-801-121	-	1615-01-210-6453	REPAIR & OVERHAUL
MASTER CYLINDER ASSEMBLY	204-076-036-055	-	-	REPAIR & OVERHAUL



B206 – B407 SERIES

UNIT	PART NUMBER	OEM	NSN	SERVICE
MAIN ROTOR HUB ASSEMBLY	206-011-100-021	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	206-011-100-127	-	-	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	206-010-450-ALL	-	-	REPAIR & OVERHAUL
MAST ASSEMBLY	206-040-002-ALL	-	-	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	206-040-021-ALL	-	-	REPAIR & OVERHAUL
FREEWHEEL ASSEMBLY	206-040-230-ALL	-	-	REPAIR & OVERHAUL
FREEWHEEL ASSEMBLY	206-040-270-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	206-040-400-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	206-040-402-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	206-011-810-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB & BLADE	206-011-810-117	-	1615-01-288-2344	REPAIR & OVERHAUL
TAIL ROTOR HUB & BLADE	206-011-810-121	-	-	REPAIR & OVERHAUL
MAIN DRIVESHAFT ASSEMBLY	206-040-015-ALL	-	-	REPAIR & OVERHAUL
ROTOR BRAKE CALIPER	4000371	-	-	REPAIR & OVERHAUL
ROTOR BRAKE CALIPER	4000397	-	-	REPAIR & OVERHAUL
ROTOR BRAKE DISC	9440904	-	1630-01-030-5435	REPAIR & OVERHAUL
MAST ASSEMBLY	206-040-014-ALL	-	-	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	206-040-004-ALL	-	-	REPAIR & OVERHAUL
FREEWHEEL ASSEMBLY	206-040-270-ALL	-	-	REPAIR & OVERHAUL
FREEWHEEL ASSEMBLY	406-040-500-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB & BLADE	206-011-810-013	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	407-010-100-ALL	-	-	REPAIR & OVERHAUL
MAST ASSEMBLY	407-040-011-ALL	-	-	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	406-010-400-ALL	-	-	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	407-040-006-ALL	-	-	REPAIR & OVERHAUL
FREEWHEEL ASSEMBLY	406-040-500-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	406-040-400-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	407-012-101-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB & BLADE	407-011-101-105	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB & BLADE	407-011-101-111	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB & BLADE	407-011-101-115	-	-	REPAIR & OVERHAUL
ROTOR BRAKE CALIPER	407-540-304-101	-	-	REPAIR & OVERHAUL
ROTOR BRAKE CALIPER	427-340-352-113	-	1680-01-627-4041	REPAIR & OVERHAUL
ROTOR BRAKE DISC	407-340-318-101	-	1680-01-617-6872	REPAIR & OVERHAUL
SERVO	41103650-009	-	1650-01-514-6829	REPAIR & OVERHAUL
SERVO	41103750-017	-	1650-01-514-6825	REPAIR & OVERHAUL
SERVO	206-076-031-013	-	-	REPAIR & OVERHAUL
SERVO	206-076-031-015	-	-	REPAIR & OVERHAUL
SERVO (TACTAIR)	206-076-031-017	-	-	REPAIR & OVERHAUL

B206 – B407 SERIES

UNIT	PART NUMBER	OEM	NSN	SERVICE
SERVO	206-076-031-021	-	1650-21-884-7814	REPAIR & OVERHAUL
SERVO (TACTAIR)	206-076-031-023	-	-	REPAIR & OVERHAUL
SERVO	206-076-031-107	-	1680-01-507-8271	REPAIR & OVERHAUL
SERVO (TACTAIR)	206-076-031-109	-	1650-21-884-7814	REPAIR & OVERHAUL
SERVO	206-076-062-001	-	-	REPAIR & OVERHAUL
SERVO (TACTAIR)	206-076-062-003	-	1680-21-906-4491	REPAIR & OVERHAUL
SERVO	206-076-062-005	-	-	REPAIR & OVERHAUL
SERVO (TACTAIR)	206-076-062-101	-	-	REPAIR & OVERHAUL
SERVO	206-076-062-103	-	-	REPAIR & OVERHAUL
SERVO	206-076-062-105	-	1680-01-617-6882	REPAIR & OVERHAUL
SERVO	206-076-062-107	-	1680-01-617-6877	REPAIR & OVERHAUL



B212 - B412 SERIES

UNIT	PART NUMBER	OEM	NSN	SERVICE
STABILIZER BAR ASSEMBLY	212-010-300-ALL	-	-	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	204-012-101-ALL	-	-	REPAIR & OVERHAUL
SCISSOR & SLEEVE ASSEMBLY	204-011-401-ALL	-	-	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	204-011-400-ALL	-	-	REPAIR & OVERHAUL
MAST ASSEMBLY	204-040-366-ALL	-	-	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	205-040-001-ALL	-	-	REPAIR & OVERHAUL
MAIN DRIVESHAFT ASSEMBLY	205-040-005-ALL	-	-	REPAIR & OVERHAUL
TAIL HANGER ASSEMBLY	212-040-600-ALL	-	-	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	212-040-003-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	212-040-004-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	212-011-701-ALL	-	-	REPAIR & OVERHAUL
ROTOR BRAKE QUILL	412-040-123-101	-	4820-01-362-8610	REPAIR & OVERHAUL
ROTOR BRAKE CALIPER	9450103-1	-	1630-00-410-9397	REPAIR & OVERHAUL
ROTOR BRAKE DISC	9440791-1	-	1630-01-047-7335	REPAIR & OVERHAUL
MASTER CYLINDER ASSEMBLY	204-076-036-005	-	1630-00-222-1065	REPAIR & OVERHAUL
MAIN ROTOR SERVO	212-076-005-007	-	1650-00-232-1434	REPAIR & OVERHAUL
MAIN ROTOR SERVO	212-076-005-011	-	-	REPAIR & OVERHAUL
MAIN ROTOR SERVO	212-076-005-101	-	1650-01-492-3360	REPAIR & OVERHAUL
MAIN ROTOR SERVO	212-076-005-103	-	1650-01-450-9360	REPAIR & OVERHAUL
MAIN ROTOR SERVO	212-076-005-105	-	1650-01-347-3055	REPAIR & OVERHAUL
MAIN ROTOR SERVO	212-076-005-107	-	1650-01-421-4775	REPAIR & OVERHAUL
MAIN ROTOR SERVO	212-076-005-111	-	1630-01-494-0350	REPAIR & OVERHAUL
TAIL ROTOR SERVO	212-076-004-005	-	-	REPAIR & OVERHAUL
TAIL ROTOR SERVO	212-076-004-101	-	1650-01-463-6071	REPAIR & OVERHAUL
TAIL ROTOR SERVO	212-076-004-103	-	-	REPAIR & OVERHAUL
SCAS ACTUATOR	41001140-001	-	-	REPAIR & OVERHAUL
CHECK VALVE	41000720	-	4820-01-252-3813	REPAIR & OVERHAUL
VALVE & FILTER	48088820-107	-	-	REPAIR & OVERHAUL
VALVE & FILTER	48088820-113	-	-	REPAIR & OVERHAUL
VALVE & FILTER	212-076-006-105	-	1650-01-483-1359	REPAIR & OVERHAUL
MAIN ROTOR HUB ASSEMBLY	412-010-100-ALL	-	-	REPAIR & OVERHAUL
MAST ASSEMBLY	412-040-366-ALL	-	-	REPAIR & OVERHAUL
HUB & SLEEVE ASSEMBLY	412-010-401-ALL	-	-	REPAIR & OVERHAUL
SWASHPLATE ASSEMBLY	412-010-402-ALL	-	-	REPAIR & OVERHAUL
COLLECTIVE LEVER ASSEMBLY	412-010-408-101	-	1630-01-253-4765	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	412-040-002-ALL	-	-	REPAIR & OVERHAUL
MAIN DRIVESHAFT ASSEMBLY	212-040-005-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR HANGER	212-040-600-005	-	-	REPAIR & OVERHAUL
TAIL ROTOR HANGER	212-040-600-101	-	1680-01-478-4333	REPAIR & OVERHAUL

B212 - B412 SERIES

UNIT	PART NUMBER	OEM	NSN	SERVICE
INTERMEDIATE GEARBOX	212-040-003-023	-	1615-01-015-0584	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	212-040-004-009	-	1615-01-008-7748	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	212-011-701-125	-	1680-01-426-0770	REPAIR & OVERHAUL
TAIL ROTOR HUB & BLADE	212-011-701-ALL	-	-	REPAIR & OVERHAUL
ROTOR BRAKE QUILL	412-040-123-101	-	4820-01-362-8610	REPAIR & OVERHAUL
ROTOR BRAKE QUILL	412-040-123-105	-	-	REPAIR & OVERHAUL
ROTOR BRAKE CALIPER	9450103-1	-	1630-00-410-9397	REPAIR & OVERHAUL
ROTOR BRAKE DISC	9440791-1	-	1630-01-047-7335	REPAIR & OVERHAUL
MASTER CYLINDER ASSEMBLY	204-076-036-005	-	1630-00-222-1065	REPAIR & OVERHAUL
TRANSMISSION ASSEMBLY	412-040-004-ALL	-	-	REPAIR & OVERHAUL
COUPLING TAIL ROTOR DRIVE	412-040-601-101	-	1680-01-475-6539	REPAIR & OVERHAUL
HANGAR COUPLING	412-040-601-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR HANGER	412-040-600-ALL	-	-	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	412-040-006-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	212-040-004-ALL	-	-	REPAIR & OVERHAUL
TAIL ROTOR HUB ASSEMBLY	212-011-701-125	-	1680-01-426-0770	REPAIR & OVERHAUL
TAIL ROTOR HUB & BLADE	212-011-701-ALL	-	-	REPAIR & OVERHAUL
ROTOR BRAKE QUILL	412-040-123-103	-	1615-01-548-7447	REPAIR & OVERHAUL
ROTOR BRAKE QUILL	412-402-107	-	-	REPAIR & OVERHAUL
ROTOR BRAKE CALIPER	9450103-1	-	1630-00-410-9397	REPAIR & OVERHAUL
ROTOR BRAKE DISC	9440791-1	-	1630-01-047-7335	REPAIR & OVERHAUL
MASTER CYLINDER ASSEMBLY	204-076-036-005	-	1630-00-222-1065	REPAIR & OVERHAUL



B214 SERIES

UNIT	PART NUMBER	OEM	NSN	SERVICE
INTERMEDIATE GEARBOX	214-040-009-007	-	-	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	214-040-009-101	-	-	REPAIR & OVERHAUL
INTERMEDIATE GEARBOX	214-040-009-109	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	214-040-011-007	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	214-040-011-107	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	214-040-011-101	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	214-040-011-111	-	-	REPAIR & OVERHAUL
TAIL ROTOR GEARBOX	214-040-011-119	-	-	REPAIR & OVERHAUL
TAIL HANGER COUPLING	214-040-600-001	-	-	REPAIR & OVERHAUL
TAIL HANGER COUPLING	214-040-600-101	-	-	REPAIR & OVERHAUL
TAIL HANGER COUPLING	214-040-600-107	-	-	REPAIR & OVERHAUL
TAIL HANGER COUPLING	214-040-600-113	-	-	REPAIR & OVERHAUL
TAIL ROTOR HANGER	214-040-600-005	-	-	REPAIR & OVERHAUL
TAIL ROTOR HANGER	214-040-600-103	-	-	REPAIR & OVERHAUL
TAIL ROTOR HANGER	214-040-600-109	-	1615-01-264-3959	REPAIR & OVERHAUL
TAIL ROTOR HANGER	214-040-600-111	-	-	REPAIR & OVERHAUL
TAIL ROTOR HANGER	214-040-600-115	-	-	REPAIR & OVERHAUL
TAIL ROTOR COUPLING	214-040-630-001	-	-	REPAIR & OVERHAUL
MAIN ROTOR SERVO	214-076-146-101	-	-	REPAIR & OVERHAUL
TAIL ROTOR SERVO	214-076-147-001	-	-	REPAIR & OVERHAUL
MAIN ROTOR SERVO	214-076-161-101	-	-	REPAIR & OVERHAUL
MAIN ROTOR SERVO	214-076-161-103	-	-	REPAIR & OVERHAUL
MAIN ROTOR SERVO	214-076-161-105	-	-	REPAIR & OVERHAUL
MAIN ROTOR SERVO	214-076-161-107	-	-	REPAIR & OVERHAUL
SCAS ACTUATOR	214-076-012-001	-	1680-00-543-7304	REPAIR & OVERHAUL



S76 Helicopter

UNIT	PART NUMBER	OEM	NSN	SERVICE
MAIN ROTOR SERVO	76650-09805-110	-	-	REPAIR & OVERHAUL
MAIN ROTOR SERVO	76650-09805-111	-	1615-01-573-9589	REPAIR & OVERHAUL
MANIFOLD REPAIR	41004076	-	5340-12-378-3214	REPAIR & OVERHAUL
MANIFOLD REPAIR	41004077	-	-	REPAIR & OVERHAUL
TAIL ROTOR SERVO	76650-05801-112	-	-	REPAIR & OVERHAUL
TAIL ROTOR SERVO	76650-05801-113	-	-	REPAIR & OVERHAUL
TAIL ROTOR SERVO	76650-05801-114	-	-	REPAIR & OVERHAUL
MAIN ROTOR DAMPER	76106-08000-049	-	1615-01-482-4541	REPAIR & OVERHAUL
MAIN ROTOR DAMPER	76106-08000-050	-	1615-01-415-7945	REPAIR & OVERHAUL
MAIN LANDING GEAR SHOCK	1945/2071 SERIES	-	-	REPAIR & OVERHAUL
MAIN LANDING GEAR	1945/2071 SERIES	-	-	REPAIR & OVERHAUL
NOSE LANDING GEAR SHOCK	1944/2070 SERIES	-	-	REPAIR & OVERHAUL
NOSE LANDING GEAR	1944/2070 SERIES	-	-	REPAIR & OVERHAUL
ENGINE TRIPOD ASSEMBLY	76309-07007-043	-	-	REPAIR & OVERHAUL
ENGINE TRIPOD ASSEMBLY	76309-07007-044	-	-	REPAIR & OVERHAUL
ENGINE TUBE ASSEMBLY	76309-07007-048	-	-	REPAIR & OVERHAUL
ENGINE TUBE ASSEMBLY	76309-07007-050	-	-	REPAIR & OVERHAUL
ENGINE TUBE ASSEMBLY	76309-07007-053	-	-	REPAIR & OVERHAUL
ENGINE TUBE ASSEMBLY	76309-07007-054	-	-	REPAIR & OVERHAUL





t T 604.746.1133 | f 604.746.1152
a 27265 Gloucester Way – Unit B101, Langley, BC V4W 3Z8
w www.cwdsys.com

S61 Helicopter

UNIT	PART NUMBER	OEM	NSN	SERVICE
AUXILIARY SERVO	S6165-61500-061	-	-	REPAIR & OVERHAUL
PRIMARY SERVO	61650-20300-041	-	-	REPAIR & OVERHAUL
PRIMARY SERVO	61650-20300-042	-	-	REPAIR & OVERHAUL
PRIMARY SERVO	61650-20300-043	-	-	REPAIR & OVERHAUL
MAIN ROTOR DAMPER	S6110-26400-041	-	-	REPAIR & OVERHAUL
LANDING GEAR	S6125-50100-005	-	-	REPAIR & OVERHAUL
LANDING GEAR	S6125-50100-006	-	-	REPAIR & OVERHAUL
LANDING GEAR	S6125-50500-001	-	-	REPAIR & OVERHAUL
LANDING GEAR	S6125-50302-001	-	-	REPAIR & OVERHAUL
LANDING GEAR	S6125-50302-002	-	-	REPAIR & OVERHAUL
PARK BRAKE VALVE	S6125-61011-000	9006	-	REPAIR & OVERHAUL
WHEEL ASSEMBLY	S6125-50203-001	-	-	REPAIR & OVERHAUL

FOR MORE INFORMATION AND PRICING CONTACT:

COREY STEINBERG
Owner / Director of Business Development
Tel: 604.746.1133 Ext. 2861
Fax: 604.746.1152
csteinberg@cwdsys.com

